



# Dragon Link Android PCB Slot Game Board For Vertical Screen Cabinet

## **Basic Information**

- Place of Origin:
- Brand Name:
- Certification:
- Model Number:
- Minimum Order Quantity: 1 Sets
- Price:
  - Packaging Details:
  - Delivery Time:
  - Payment Terms:
    - r aymont ronno.
  - Supply Ability:

## Negotiable Wooden box 5-20days visa, mastercard, T/T, PAYPAL, APPLE\_PAY, GOOGLE\_PAY, GC\_REAL\_TIME\_BANK\_TRANSFER 1000 Sets/month



Dragon Link Android PCB Slot Game Board • Name: For Vertical Screen Cabinet • Games: 4 ln 1 • Screen: 43 Inch, 32 Inch Vertical Screen English / Chinese • Language: • Difficulty: 85-98% Adjustable • Play Type: Bill Acceptor, Key In, Card System Printer, Mutha Goose, Key Out, Card System • Payout Type: Control Panel: Buttons, Ideck Touch Panel 12V Voltage: • Player: One • Highlight: android slot game board, android slot machine boards, vertical slot game board

Guangzhou Haichang

Dragon Link

ISO CE



### More Images





## **Product Description**

#### Dragon Link Android PCB Slot Game Board For Vertical Screen Cabinet

#### **Product Parameter**

| Name          | Lightning Link Android PCB Slot Game Board For Vertical Screen Cabinet |
|---------------|--|
| Games         | 4 in 1   |
| Screen        | 43 Inch, 32 inch vertical screen                                       |
|               | English / Chinese  |
| Difficulty    | 85-98% adjustable  |
| Play Type     | Bill acceptor, Key in, Card system                                     |
| Payout Type   | Printer, Mutha Goose, Key out, Card system                             |
| Control Panel | Buttons, Ideck Touch Panel   |
| Voltage       | 12V  |
| Player        | One  |

#### How To Assemble Slot Game Board

How slot machine game boards are installed will vary depending on the specific slot machine model and design. Here are the general steps for installing a slot machine game board in general:

Preparation: Make sure you have turned off the power to your slot machine and unplugged it from the outlet. Make sure you have the appropriate tools and required installation materials.

Remove the old board (if applicable): If you are replacing the game board on your slot machine, you will first need to remove the old board. This may involve uncoupling cables, removing retaining screws, or other means of mounting. Please use caution during this process to avoid damaging other components.

Install the new board: Place the new game board in the appropriate location on the slot machine. If necessary, reconnect the cables and secure the board appropriately. Make sure connections are made correctly and handle wires and connectors carefully to avoid damage.

Testing and Tweaking: After reinstalling the game board, reconnect power and start the slot machine. Do some tests to make sure the game board is working properly. Check that all functions, buttons and display are functioning properly. If any issues are found, further adjustments or connections may need to be checked.

Please note that the above steps are general guidelines and the specific installation process may vary depending on the slot machine model, manufacturer and design. For your specific slot machine, it's best to refer to the installation manual provided by the manufacturer or contact a professional repairman for more specific installation instructions.

